

MIRRORLITE MIRROR CEILING HANGING KIT INSTRUCTIONS

1) UNPACK THE SMALL WHITE BOX WITH THE HARDWARE

2) PLEASE LOCATE 4 LENGTHS OF 5 FEET LOOPCHAIN WITH 'S' HOOKS AND EYEBOLTS ATTACHED



3) LOCATE THE THREADED INSERT ON THE BACK OF THE MIRROR IN EACH CORNER BY RED TAPE



4) THREAD EYEBOLT INTO EACH CORNER AND TIGHTEN LOCK NUT WITH WRENCH